

recommended lengths

for Nordic skis



Ski length [cm]	150	160	164	165	166	170	172	174	175	179	180	181	182	185	187	189	190	194	195	197	200	201	205	208	210
FAVORIT	25-35	30-40			38-47						45-55			50-60		55-65	55-65		60-72		66-78		75-86		82-95
FAVORIT W					38-47						45-55			50-60		55-65	55-65		60-72		66-78				
ADVENTURE		50-60			60-70						70-80					79-88									
HIGHLANDER											50-60			55-65		61-70			66-77		72-88		80-91		87-100
FORESTER				60-70					70-80					78-90					89-97				95-102		
RANGER		55-65			65-75					75-87						86-94									
VEGA					30-40					40-50								60-70				70-80			
PERUN					60-75			75-90					85-100												
PERUN W					60-75			75-90					85-100												
RUBICON			65-80								90-105														
SPRINT Classic	22-29	25-35			30-40						40-50			50-60				60-70				70-80		80-90	
SPRINT Combi		30-40			40-48					45-55			55-65					65-75				75-78		85-95	
SPRINT Skate		30-40			40-50					50-60			60-70					70-80				80-90			
BOHEMIA XS Classic											60-70												90-100		
BOHEMIA XS Skate														70-85											85-100

The table is informative only. The right length of ski will be recommended by an expert staff of shop with respect to your skiing style and terrain you will go skiing in. The final choice can be different from that written in the table.